

Operating Instructions

DESCRIPTION:

The EnviroReel is a field rugged, 100% recyclable product made from post consumer recycled and new materials.

The EnviroReel replaces the Reel-In-Box coaxial cable dispenser, reducing non-recyclable waste and providing a reuseable cable dispenser.

The cable reel can only be used with the EnviroReel system, ensuring that approved product is applied to the installation.

FEATURES

EXTERIOR

Foot Receiver

Cable Restraint

Latch Release Button

Foot (Nestable)



INTERIOR

Foot Receiver

Cable Reel Assembly

Latch Release Button

Security Key



REEL

Security Key

Cable Reel Assembly



ASSEMBLE



Operating Instructions

OPERATION

- STEP 1: On a flat and stable surface, open the EnviroReel by depressing the latch lock
- STEP 2: Insert the security key to the cable reel
- STEP 3: Place the cable reel into the EnviroReel case
- STEP 4: Unwrap and prepare the cable reel
- STEP 5: Close the EnviroReel lid
- STEP 6: Place the cable end into the cable restraint provided. To dispense cable, remove the cable from the restraint and pull the length required. Cut the cable to the desired length and place the cable end back into the restraint prior to moving the EnviroReel.



ATTENTION

- WARNING: This product is not a toy. Do not permit access to children.
- WARNING: This product is not a step; do not stand on product.
- WARNING: Rotating parts inside; do not place fingers or objects inside while operating.
- WARNING: Pinch hazard; use caution when closing.
- CAUTION: For use with approved products only; do not adapt for use with unapproved product.
- CAUTION: Do not drop, toss or throw.
- CAUTION: Do not place heavy objects or weight on top of product.
- CAUTION: Use care when operating.